




Step 1

Lay out all the Frame poles according to size. Grab the 2 Large Frame Poles and 1 Frame connector.




Step 2

Remove the screws and washers on the frame connector and slide the connector through the opening in the frame, lining up the screw hole.




Step 3

Place a screw and a washer in the screw hole and tighten. Repeat for the other Frame bar. You want to make sure the Angle on the frame bars are on each side.



Step 4

Grab 1 Medium Frame bar with feet drill holes on the side and one regular Medium bar without feet drill holes.



Step 5

Grab 1 connector and remove the screws and washers on the frame connector and slide the connector through the opening in the frame lining up the screw hole.




Step 6

Place a screw and washer in the screw hole and tighten. Repeat for the other Frame bar. You want to make sure the Angle on the frame bars are on each side. Repeat this step for the other 2 Medium Frame poles



Step 7

Grab 2 Screw Curved corner Bracket and one Flat Corner Bracket, un-tightening the screws a little bit so the flat corner bracket and the screw corner bracket are flat enough to insert into the angled corners of the frame bars.



Step 8

Make sure the screws are face out from the frame and the flat edge of the frame is lined up. After inserting the curved corner brackets and connecting the frame bars together, tighten the screws very tightly to ensure a tight fit.



Step 9

Repeat step 7&8 for all corners making sure the flat edge of the frame is lined up and that all the screws are very tight.